


Connecting the Plamp Clamp to your Plamp

1. Remove the old clamp end from the Plamp by firmly grabbing the Loc-Line® segment *next* to the end segment that is attached to the clamp. Bend it sharply until the segments pop apart. (do not worry, you will not hurt the Plamp)



2. To attach the new clamp, forcefully press it onto the segment that was previously attached to the old clamp. It should snap into place with an audible “pop”. It takes a substantial amount of pressure to make this happen. It helps to place your fists between your knees, holding the mating pieces as close to the connecting joint as possible. Squeeze your knees together forcefully as you force the joints together with your hands. If you are still having difficulty you can heat up the female socket to facilitate the process (details below).



Heating the female socket:

Heat some water to boiling or near-boiling temperature.

Warm the female end of the segment for 30-60 seconds in the hot water.


Connect the segments by pushing them together.

Use the knee-squeezing technique mentioned above if needed.

The segments should pop into place fairly easily.

Wimberley

PP-220 The Plamp II Clamp



Weight: 3.3 oz

Dimensions (L x W x H): 4.5" x 3" x 1.4"

Package Contents:

- The Plamp Clamp (Qty 1)

Made in USA 

Wimberley, Inc.
1750 Broadway St
Charlottesville, VA
22902 USA

Phone: 1-434-529-8385

Toll Free: 1-888-665-2746 (USA & Canada)

www.tripodhead.com

info@tripodhead.com

10 Year Warranty – See www.tripodhead.com/warranty.cfm for complete details

Thank you for your interest in Wimberley products. If you have any questions or comments feel free to contact us.